

M-7084

User Manual

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for damages resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notification. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, or for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright 1999 - 2012 ICP DAS. All rights reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Date: 2019/3/4

Table of Contents

1. Introduction	5
1.1 More Information	6
1.2 Terminal Assignment	7
1.3 Specifications	8
1.3.1 I/O Specifications	8
1.3.2 System Specifications	9
1.4 Block Diagram	10
1.4.1 Block Diagram for the M-7084.....	10
1.5 Dimensions	11
1.6 Wiring.....	12
1.6.1 M-7084 Wiring.....	12
1.6.2 Wiring Recommendations.....	12
1.7 Quick Start.....	13
1.8 Default Settings	15
1.9 Configuration Tables.....	16
1.10 M-7000 Notes.....	20
1.10.1 Protocol Switching	20
1.10.2 INIT Mode.....	21
1.11 Mounting	22
1.11.1 Din-Rail Mounting	22
1.11.2 Piggyback Mounting	24
1.11.3 Wall Mounting	25
1.12 Technical Support	26
2. DCON Protocol	27
2.1 %AANNTTCCFF	31
2.2 #AA	34
2.3 #AAN	35
2.4 \$AA0N	37
2.5 \$AA0N(Data)	39
2.6 \$AA2	41
2.7 \$AA3N	43
2.8 \$AA3N(Data)	45
2.9 \$AA4	47
2.10 \$AA4VV	49
2.11 \$AA5	51

2.12 \$AA5VV	53
2.13 \$AA6	55
2.14 \$AA6N	57
2.15 \$AA7	59
2.16 \$AA7VV	61
2.17 \$AA7CNRVV	63
2.18 \$AA8CN.....	65
2.19 \$AAF	67
2.20 \$AAI.....	68
2.21 \$AAM.....	70
2.22 \$AAP	71
2.23 \$AAPN	73
2.24 @AABB	75
2.25 @AABBVV	77
2.26 @AAFA	79
2.27 @AAFAVV	81
2.28 @AAFH	83
2.29 @AAFHVV	85
2.30 @AAFT	87
2.31 @AAFTVV	89
2.32 @AAGN.....	91
2.33 @AAPN(Data)	93
2.34 @AASC.....	95
2.35 @AASCVV	97
2.36 ~**	99
2.37 ~AA0	100
2.38 ~AA1	102
2.39 ~AA2	104
2.40 ~AA3EVV.....	106
2.41 ~AAI.....	108
2.42 ~AAO(Name)	110
2.43 ~AARD.....	112
2.44 ~AARDVV	114
2.45 ~AATnn.....	116
3. Modbus RTU Protocol	119
3.1 M-7084 Modbus Address Mapping	120
4. Troubleshooting.....	122
4.1 Communicating with the module	123


A. Appendix	124
A.1 INIT Mode	124
A.2 Dual Watchdog Operation.....	126
A.3 Frame Ground.....	127
A.4 Node Information Area	129
A.5 Reset Status	130
A.6 Frequency Measurement	131

1. Introduction

The I-7000 series is a family of network data acquisition and control modules, providing analog-to-digital, digital-to-analog, digital input/output, timer/counter and other functions. The modules can be remotely controlled using a set of commands, which we call the DCON protocol. Communication between the module and the host is in ASCII format via an RS-485 bi-directional serial bus standard. Baud Rates are software programmable and transmission speeds of up to 115.2 Kbps can be selected.

The functionality of the M-7000 series is the same as the I-7000 series, with the exception that the M-7000 series offers extended support for the Modbus RTU protocol.

Some M-7000 modules feature a new design for the frame ground and INIT switch as shown in the figure (rear view). The frame ground provides enhanced static protection (ESD) abilities and ensures the module is more reliable. The INIT switch allows easier access to INIT mode. Please refer to Sections A.1 and A.3 for more details.



The M-7084 supports up counting, up-down counting, pulse direction counting, quadrature counting and frequency measurement.


1.1 More Information

For more information regarding the I-7000/M-7000 series, please refer to chapter 1 of the “I-7000 Bus Converter User’s Manual” as shown below or visit the ICP DAS website <http://www.icpdas.com>.

- 1.1 The 7000 Series Overview
- 1.2 Related Documentation for the 7000 Series
- 1.3 Common Features of the 7000 Series
- 1.4 The 7000 Series System Network Configuration
- 1.5 7000 Dimensions

- For details of **INIT mode** operation, please refer to Section A.1 INIT Mode.
- For details of **module watchdog** and **host watchdog**, please refer to Section A.2 Dual Watchdog Operation.
- For details of **ESD protection** and **grounding**, please refer to Section A.3 Frame Ground.
- The **node information area** can be written with some information, please refer to Section A.4 Node Information Area for details.
- There is a way to check whether the module is reset, please refer to Section A.5 **Reset Status** for details.
- For details of **frequency measurement**, please refer to Section A.6 Frequency Measurement.

1.2 Terminal Assignment



1.3 Specifications

1.3.1 I/O Specifications


Counter/Frequency/Encoder Input	
Channels	4-channel Up/Down Counter (CW/CCW) 4-channel Direction/Pulse Counter (Bi-direction) 4-channel A/B Phase (Quadrature Counting) 8-channel Up Counter 8-channel Frequency
Contact	Wet
Sink/Source (NPN/PNP)	Sink
Types	Counter, Frequency, Encoder
Counter/Encoder Bits	32-bit (4,294,967,295)
On Voltage Level	+3.5 VDC ~ +30 VDC
Off Voltage Level	+1 VDC Max.
Programmable Digital Filter	1 ~ 32767 μ s
Individual Channel Configuration	Yes
Counter Mode	Up, Up/Down
Encoder Mode	CW/CCW, Direction/Pulse, AB Phase
Frequency Mode	Yes
Max. Speed	3.5 VDC ~ 10 VDC: 200 kHz 10 VDC ~ 30 VDC: 150 kHz
Frequency Accuracy	\pm 0.4% of Input Frequency
Virtual Battery Backup to Preserve Counter Values	Yes

1.3.2 System Specifications



Communication	
Interface	RS-485
Format	N81, N82, E81, O81
Baud Rate	1200 ~ 115200 bps
Protocol	Modbus RTU, DCON
Dual Watchdog	Yes, Module (1.6 Seconds), Communication (Programmable)
LED Indicator	
Power	1 LED, Red
Isolation	
Intra-module Isolation, Field-to-Logic	3000 VDC
EMS Protection	
ESD (IEC 61000-4-2)	+/-4 kV Contact for Each Terminal
EFT (IEC 61000-4-4)	+/-4 kV for Power
Surge (IEC 61000-4-5)	+/-3 kV for Power Line
Power	
Reverse Polarity Protection	Yes
Input Range	10 ~ 30 VDC
Consumption	1.32 W Max.
Mechanical	
Dimensions (W x L x H)	72 mm x 123 mm x 35 mm
Installation	DIN-Rail, Wall Mounting
Environment	
Operating Temperature	-25 ~ +75°C
Storage Temperature	-30 ~ +80°C
Humidity	10 ~ 90% RH, Non-condensing

1.4 Block Diagram


1.4.1 Block Diagram for the M-7084



1.5 Dimensions



Unit : mm



1.6 Wiring

1.6.1 M-7084 Wiring

Counter Type	
Up	
Up/Down	
Dir/Pulse	
A/B Phase	
Frequency Type	
Frequency	

1.6.2 Wiring Recommendations

- Use 26-12 AWG wire for signal connections.
- Strip the wire to a length of 7 ± 0.5 mm.
- Use a crimp terminal for wiring.
- Avoid high-voltage cables and power equipment as much as possible.
- For RS-485 communication, use insulated and twisted pair 24 AWG wire, e.g. Belden 9841.

1.7 Quick Start

To install the module, follow the steps below:

1. Refer to Section 1.2 for the terminal assignment and Section 1.6 for the wiring diagram.
2. Connect the module to the RS-485 network using the DATA+ and DATA- terminals. See Section 1.2 for the terminal assignment. If the host is only equipped with an RS-232 interface, then an RS-232 to RS-485 converter will be required. Refer to the “**I-7000 Bus Converter User’s Manual**” for more information.
3. Connect the module to the power supply using the +Vs and GND terminals. See Section 1.2 for the terminal assignment. Note that the voltage supplied to the module should be in the range of +10 to +30 VDC.
4. Configure the module by sending the %AANNTTCCFF command and the \$AA7CNRVV command. See Section 2.1 and 2.17 for details. For M-7000 modules using the Modbus RTU protocol, configure the module using the following registers: 40257 ~ 40264, 40485, and 40486. The default settings for the module can be found in Section 1.8.
5. To read data from the input channels, send the #AAN command to the module. See Sections 2.3 for details. For M-7000 modules using the Modbus RTU protocol, use Function 03h to read the data from the input channels.
6. If the host is a PC with a Windows operating system installed, the DCON Utility can be used to allow easy configuration and reading of data. The DCON Utility can be downloaded from the ICP DAS website (<http://www.icpdas.com>). The documentation for the DCON Utility can be found in the “**Getting Started For I-7000 Series Modules**” manual.

Please refer to the “**I-7000 Bus Converter User’s Manual**” and “**Getting Started For I-7000 Series Modules**” manuals for more details. The “**Getting Started For I-7000 Series Modules**” manual can be downloaded from the ICP DAS website (<http://www.icpdas.com>).

1.8 Default Settings

Default settings for the M-7084 modules are as follows:

- Protocol: Modbus RTU
- Module Address: 01
- Type: Type 50, up counter
- Baud Rate: 9600 bps

1.9 Configuration Tables

Baud Rate Setting (CC)

7	6	5	4	3	2	1	0
Data		Baud					

Key	Description
Baud	Baud Rate 03: 1200 04: 2400 05: 4800 06: 9600 07: 19200 08: 38400 09: 57600 0A: 115200
Data	Data Format 0: eight data bits, no parity, and one stop bit 1: eight data bits, no parity, and two stop bit 2: eight data bits, even parity, and one stop bit 3: eight data bits, odd parity, and one stop bit

Type Setting (TT)

Type Code	Input Type
50	Up counter
51	Frequency
54	Up/down counter
55	Pulse/direction counter
56	Quadrature counter

Data Format Setting (FF)

7	6	5	4	3	2	1	0
RD	CS	RD				DF	


Key	Description
DF	Data format 00: Engineering unit. The data consist of '+', 6 digits and one decimal point. This data format is only for the frequency type. 10: Hexadecimal
CS	Checksum setting 0: Disabled 1: Enabled
RD	Reserved

Note: The reserved bits should be zero.

Counter Type and Data Format Table


Type Code	Counter type	Data Format	Min	Max
50	Up	Hex	00000000	FFFFFFFF
54	Up/down	Hex	80000000	7FFFFFFFFF
55	Pulse/direction	Hex	80000000	7FFFFFFFFF
56	Quadrature	Hex	80000000	7FFFFFFFFF

Up/down Counting





When InA0 is used as an up counting clock and InB0 is used as a down counting clock, the counter will be increased by one for every falling edge of InA0 and decreased by one for every falling edge of InB0.

Pulse/direction Counting



The InB0 is used for direction counting. When InB0 is high, the counter will be increased by one for every falling edge of InA0. When InB0 is low, the counter will be decreased by one for every falling edge of InA0.

Quadrature Counting



When InA0 is used as the A signal and InB0 is used as the B signal, the counter will be increased by one when the InA0 phase leads by 90 degrees to InB0 and the counter will be decreased by one when the InA0 phase lags by 90 degrees to InB0.

1.10 M-7000 Notes

The main difference between the I-7000 and M-7000 series is that the M-7000 series has additional support for the Modbus RTU communication protocol, which is the default protocol of the M-7000 series. The communication Baud Rates for the Modbus RTU protocol can be in the range of 1200 bps to 115200 bps.

Modbus functions supported by the module are described in Chapter 3.

1.10.1 Protocol Switching

To switch to the DCON protocol:

1. Set Modbus register 00257 to 0. See Section 3.1 for details.
2. After a power-on reset, the communication protocol will be changed to DCON.

To switch to the Modbus RTU protocol:


1. Sends the \$AAPN command and set N to a value of 1.
Note that for the modules without frame ground, the INIT* terminal should be connected to the GND terminal, and for the modules with frame ground, the slide switch on the rear side of the module should be set to the INIT position, see the figure on the next page. See Section 2.23 for details.
2. After a power-on reset, the communication protocol will be changed to the Modbus RTU protocol.

1.10.2 INIT Mode

When the module is powered on, with the rear slide switch set to the INIT position as shown in the figure below for modules with frame ground, or with the INIT* pin connected to the GND pin for modules without frame ground, the module is in INIT mode, (see Section A.1 for details), and the communication settings are as follows:


1. Address: 00
2. Baud Rate: 9600 bps
3. No checksum
4. Protocol: DCON

If communication with the module is not possible, set the module to the INIT mode and use the above settings to communicate with the module. To read the current settings, send the commands \$AA2, (see Section 2.6), and \$AAP, (see Section 2.22). To set new settings, send the commands %AANNTTCCFF, (see Section 2.1) and \$AAPN, (see Section 2.23). The new communication settings will be effective after the next power-on reset.



1.11 Mounting

1.11.1 Din-Rail Mounting




There are three new DIN rail models available. Each is made of stainless steel, which is stronger than those made of aluminum. There is a screw at one end and a ring terminal is included so that it can be easily connected to the earth ground. The three new DIN rail models are as follows.

Part number	Max. number of modules	Dimensions
DRS-360	5	360mm x 35mm

A perspective view of a single DIN rail module. A cable is connected to a ring terminal on the left side of the module. An arrow points from the text 'to earth ground' to this terminal.


to earth ground

Part number	Max. number of modules	Dimensions
DRS-240	3	240mm x 35mm



The diagram shows three DRS-240 modules mounted on a DIN rail. A wire is connected to the rail, with an arrow pointing down to the text "to earth ground".


Part number	Max. number of modules	Dimensions
DRS-125	2	125mm x 35mm




The diagram shows two DRS-125 modules mounted on a DIN rail. A wire is connected to the rail, with an arrow pointing down to the text "to earth ground".

Note: It is recommended that a 16 – 14 AWG wire is used to connect the DIN rail to the earth ground.

1.11.2 Piggyback Mounting



1.11.3 Wall Mounting



1.12 Technical Support

Should you encounter any problems while using the I-7000 and M-7000 module, and are unable to find the help you need in this manual or on our website, please contact ICP DAS Product Support.

Email: service@icpdas.com

Website:

http://www.icpdas.com.tw/contact_us/contact_us.html

When requesting technical support, be prepared to provide the following information about your system:

1. Module name and serial number: The serial number can be found printed on the barcode label attached to the cover of the module.
2. Firmware version: See Sections 2.19 and 3.1 for information regarding the command used to identify the firmware version.
3. Host configuration (type and operating system)
4. If the problem is reproducible, please give full details describing the procedure used to reproduce the problem.
5. Any specific error messages displayed. If a dialog box with an error message is displayed, please include the full text of the dialog box, including the text in the title bar.
6. If the problem involves other programs or hardware devices, please describe the details of the problem in full.
7. Any comments and suggestions related to the problem are welcome.

ICP DAS will reply to your request by email within three business days.

2. DCON Protocol

All communication with I-7000 modules consists of commands generated by the host and responses transmitted by the I-7000 modules. Each module has a unique ID number that is used for addressing purposes and is stored in non-volatile memory. The ID is 01 by default and can be changed using a user command. All commands to the modules contain the ID address, meaning that only the addressed module will respond. The only exception to this is command ~** (Section 2.36), which is sent to all modules, but the modules do not reply to the command.

Command Format:

Leading Character	Module Address	Command	[CHKSUM]	CR
--------------------------	-----------------------	----------------	-----------------	-----------

Response Format:

Leading Character	Module Address	Data	[CHKSUM]	CR
--------------------------	-----------------------	-------------	-----------------	-----------

CHKSUM A 2-character checksum which is present when the checksum setting is enabled. See Sections 1.9 (Data Format Setting) and 2.1 for details.

CR End of command character, carriage return (0x0D)

Checksum Calculation:

1. Calculate the ASCII code sum of all the characters in the command/response string except for the carriage return character (CR).
2. The checksum is equal to the sum masked by 0FFh.

Example:

Command string: \$012(CR)

1. Sum of the string = "\$"+"0"+"1"+"2" =
 $24h+30h+31h+32h = B7h$
2. Therefore the checksum is B7h, and so
CHKSUM = "B7"
3. The command string with the checksum = \$012B7(CR)

Response string: !01200600(CR)

1. Sum of the string =
"!"+ "0"+"1"+"2"+"0"+"0"+"6"+"0"+"0" =
 $21h+30h+31h+32h+30h+30h+36h+30h+30h = 1AAh$
2. Therefore the checksum is AAh, and so
CHKSUM = "AA"
3. The response string with the checksum
= !01200600AA(CR)

Note:

All characters should be in upper case.

General Command Sets			
Command	Response	Description	Section
%AANNTTCCFF	!AA	Sets the Module Configuration	2.1
\$AA2	!AANNTTCCFF	Reads the Module Configuration	2.6
\$AA5	!AAS	Reads the Reset Status	2.11
\$AAF	!AA(Data)	Reads the firmware Version	2.19
\$AAI	!AAS	Reads the INIT Status	2.20
\$AAM	!AA(Data)	Reads the Module Name	2.21
\$AAP	!AASC	Reads the communication protocol	2.22
\$AAPN	!AA	Sets the communication protocol	2.23
~AAI	!AA	Software INIT	2.41
~AAO(Name)	!AA	Sets the Module Name	2.42
~AARD	!AAVV	Reads the Response Delay Time	2.43
~AARDVV	!AA	Sets the Response Delay Time	2.44
~AATnn	!AA	Sets the Software INIT Timeout	2.45

Counter/Frequency Command Sets			
Command	Response	Description	Section
#AA	>(Data)	Reads the Input Data of All Channels	2.2
#AAN	>(Data)	Reads the Input Data of the Specified Channel	2.3
\$AA0N	!AA(Data)	Reads the Low Pass Filter Time of the Specified Channel	2.4
\$AA0N(Data)	!AA	Sets the Low Pass Filter Time of the Specified Channel	2.5
\$AA3N	!AA(Data)	Reads the Maximum Counter Value of the Specified Channel	2.7
\$AA3N(Data)	!AA	Sets the Maximum Counter Value of the Specified Channel	2.8
\$AA4	!AAVV	Reads the Low Pass Filter Channel Mask	2.9
\$AA4VV	!AA	Sets the Low Pass Filter Channel Mask	2.10
\$AA5VV	!AA	Starts/Stop Counting	2.12
\$AA6	!AAVV	Reads the Start/Stop Counting Status	2.13

Command	Response	Description	Section
\$AA6N	!AA	Clears the Counter Value of the Specified Channel	2.14
\$AA7	!AAVV	Shows the Overflow Status of All Channels	2.15
\$AA7VV	!AA	Clears the Overflow Status	2.16
\$AA7CNRVV	!AA	Sets the Single Channel Type	2.17
\$AA8CN	!AACNRVV	Reads the Channel Type of the Specified Channel	2.18
@AABB	!AAVV	Reads the Battery Backup Status	2.24
@AABBVV	!AA	Sets the Battery Backup Status	2.25
@AAFA	!AAVV	Reads the Auto Frequency Mode Status	2.26
@AAFAVV	!AA	Sets the Auto Frequency Mode Status	2.27
@AAFH	!AAVV	Reads the High Frequency Mode Status	2.28
@AAFHVV	!AA	Sets the High Frequency Mode Status	2.29
@AAFT	!AAVV	Reads the Frequency Measurement Timeout	2.30
@AAFTVV	!AA	Sets the Frequency Measurement Timeout	2.31
@AAGN	!AA(Data)	Reads the Preset Counter Value of the Specified Channel	2.32
@AAPN(Data)	!AA	Sets the Preset Counter Value of the Specified Channel e	2.33
@AASC	!AAVV	Reads the Stop Counting on Overflow Status	2.34
@AASCVV	!AA	Sets the Stop Counting on Overflow Status	2.35

Host Watchdog Command Sets			
Command	Response	Description	Section
~**	No Response	Host OK	2.36
~AA0	!AASS	Reads the Status	2.37
~AA1	!AA	Resets the Status	2.38
~AA2	!AAVV	Reads the Timeout Settings	2.39
~AA3EVV	!AA	Sets the Timeout Settings	2.40

2.1 %AANNTTCCFF

Description:

Sets the configuration of a module.

Syntax:

%AANNTTCCFF[CHKSUM](CR)

%	Delimiter character
AA	Address of the module to be configured in hexadecimal format (00 to FF)
NN	New address of the module in hexadecimal format (00 to FF)
TT	New type code. Not used by the M-7084. It should be set to 00 for the M-7084
CC	New Baud Rate code, see Section 1.9 for details. The INIT* pin must be connected to ground in order to change Baud Rates. For the module with frame ground, this is achieved by moving the rear slide switch to the INIT position. See Section A.1 for details.
FF	Used to set the data format and checksum (Section 1.9). The INIT* pin must be connected to ground in order to change the checksum setting. For the module with frame ground, this is achieved by moving the rear slide switch to the INIT position. See Section A.1 for details.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter for a valid command

? Delimiter for an invalid command. If the **Baud Rate** or **checksum** settings are changed without connecting the INIT* pin to ground or switching the rear slide switch to the INIT position, the module will return an invalid command.

AA Address of the module in hexadecimal format (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: %0102000600 Response: !02

Changes the address of module 01 to 02. The module returns a valid response.

Command: %0101000A00 Response: ?01

Changes the Baud Rate of module 01 to 115200bps. The module returns an invalid command, because it is not in INIT* mode.

Command: %0101000A00 Response: !01

Changes the Baud Rate of module 01 to 115200bps and the module is in INIT* mode. The module returns a valid response.

Related Commands:

Section 2.6 \$AA2, Section 2.41 ~AAI, Section 2.45 ~AATnn

Related Topics:

Section 1.9 Configuration Tables, Section A.1 INIT* pin Operation

Notes:

1. Changes to the address and data format settings take effect immediately after a valid command is received. Changes to the Baud Rate and checksum settings take effect on the next power-on reset.
2. For the M-7084, changing the Baud Rate and checksum settings can be achieved using software only and is performed using the following commands:
 - I. Send a ~AATnn command. See Section 2.45 for details.
 - II. Send a ~AAI command. See Section 2.41 for details.
 - III. Send a %AANNTTCCFF command.
If the command is valid, the Baud Rate and checksum settings will be changed after the module responds with !AA.

2.2 #AA

Description:

Reads the data from every input channels.

Syntax:

#AA[CHKSUM](CR)

Delimiter character

AA Address of the module to be read (00 to FF)

Response:

Valid Response: **>(Data)[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

> Delimiter character for a valid response

? Delimiter character for an invalid response

(Data) Data from every input channels, see Section 1.9 for the details of data format.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #01

Response:

>000012340000567800009ABC0000DEF000001111000022
2200000333300004444

Reads module 01 and receives the data.

Related Commands:

Section 2.1 %AANNTTCCFF, Section 2.6 \$AA2

Related Topics:

Section 1.9 Configuration Tables

2.3 #AAN

Description:

Reads the input of channel N.

Syntax:

#AAN[CHKSUM](CR)

#	Delimiter character
AA	Address of the module to be read (00 to FF)
N	The channel to be read, zero based.

Response:

Valid Response: **>(Data)[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

>	Delimiter character for a valid response
?	Delimiter character for an invalid response. An invalid command is returned if the specified channel is incorrect.
(Data)	Input data of the specified channel, see Section 1.9 for details of the data format.
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: #032

Response: >00001234

Reads data from channel 2 of module 03.

Command: #029

Response: ?02

Reads data from channel 9 of module 02. An error is returned because channel 9 is invalid.

Related Commands:

Section 2.1 %AANNTTCCFF, Section 2.6 \$AA2

Related Topics:

Section 1.9 Configuration Tables

2.4 \$AA0N

Description:

Reads the low pass filter time of channel N.

Syntax:

\$AA0N[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be set (00 to FF)

0 Command to read the low pass filter time of a channel

N Specifies the channel to be read (0 ~ 7)

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

(Data) Low pass filter time is micro seconds, consisting of 5 decimal digits in the range 00001 ~ 32767.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0103 Response: !0100010

Reads the channel 3 low pass filter time of module 01 and the module responds with 00010 which means 10 micro seconds.

Related Commands:

Section 2.5 \$AA0N(data), Section 2.9 \$AA4, Section 2.10 \$AA4vv

Notes:

1. The low pass filter time should be the same for channel 0 and 1. When it is set to either one of the channel 0 or 1, both channels will be set to the same value.
2. The low pass filter time should be the same for channel 2 and 3. When it is set to either one of the channel 2 or 3, both channels will be set to the same value.
3. The low pass filter time should be the same for channel 4, 5, 6 and 7. When it is set to either one of the channel 4, 5, 6 or 7, all of the 4 channels will be set to the same value.

2.5 \$AA0N(Data)

Description:

Sets the low pass filter time of a channel.

Syntax:

\$AA0N(Data)[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be set (00 to FF)

0 Command to read the low pass filter time of a channel

N Specifies the channel to be read (0 ~ 7)

(Data) Low pass filter time is micro seconds, consisting of 5 decimal digits in the range 00001 ~ 32767.

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$010300010 Response: !01

Sets the channel 3 low pass filter time of module 01 to 10 micro seconds and returns a valid response.

Related Commands:

Section 2.4 \$AA0N, Section 2.9 \$AA4, Section 2.10 \$AA4vv

Notes:

1. The low pass filter time should be the same for channel 0 and 1. When it is set to either one of the channel 0 or 1, both channels will be set to the same value.
2. The low pass filter time should be the same for channel 2 and 3. When it is set to either one of the channel 2 or 3, both channels will be set to the same value.
3. The low pass filter time should be the same for channel 4, 5, 6 and 7. When it is set to either one of the channel 4, 5, 6 or 7, all of the 4 channels will be set to the same value.

2.6 \$AA2

Description:

Reads the module configuration.

Syntax:

\$AA2[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be read (00 to FF)
2	Command to read the module configuration

Response:

Valid Command: **!AATTCFF[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
TT	Type code of the module, should be 00 for M-7084.
CC	Baud Rate code of the module, see Section 1.9 for details.
FF	Checksum and counter update direction settings of the module, see Section 1.9 for details.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$012

Response: !01000600

Reads the configuration of module 01.

Related Commands:

Section 2.1 %AANNTTCCFF

Related Topics:

Section 1.9 Configuration Tables

2.7 \$AA3N

Description:

Reads the maximum counter value of channel N.

Syntax:

\$AA3N[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be set (00 to FF)
3	Command to read the maximum counter value of a channel
N	Specifies the channel to be read (0 ~ 7)

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
(Data)	The maximum counter value in eight hexadecimal digits

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0132 Response: !01FFFFFFFF

Reads the channel 2 maximum counter value of module 01 and the module responds with FFFFFFFFFF.

Related Commands:

Section 2.8 \$AA3N(Data)

Note:

The maximum counter value is only available to the channels that are set to up counter type (type code 50).

2.8 \$AA3N(Data)

Description:

Sets the maximum counter value of a channel.

Syntax:

\$AA3N(Data)[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be set (00 to FF)
3	Command to set the maximum counter value of a channel
N	Specifies the channel to be read (0 ~ 7)
(Data)	The maximum counter value in eight hexadecimal digits

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0132F0000000 Response: !01

Sets the channel 2 maximum counter value of module 01 to 0xF0000000 and returns a valid response.

Related Commands:

Section 2.7 \$AA3N

Note:

The maximum counter value is only available to the channels that are set to up counter type (type code 50).

2.9 \$AA4

Description:

Reads the enabled/disabled low pass filter status of each channel.

Syntax:

\$AA4[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

4 Command to read the low pass filter status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

VV A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the low pass filter is enable for the channel and 0 means that the low pass filter is disabled for the channel.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$014

Response: !013A

Reads the low pass filter enabled/disabled status for module 01 and returns a response of 3A, meaning that low pass filter for channels 1, 3, 4, and 5 are enabled and disabled for all other channels.

Related Commands:

Section 2.10 \$AA4VV

2.10 \$AA4VV

Description:

Specifies the channel(s) which low pass filter should be enabled.

Syntax:

\$AA4VV[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be read (00 to FF)
4	Command to enable/disable the low pass filter
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the low pass filter is enable for the channel and 0 means that the low pass filter is disabled for the channel.

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0143A

Response: !01

Enables the low pass filter of channels 1, 3, 4, and 5 and disables all other channels of module 01. The module returns a valid response.

Related Commands:

Section 2.9 \$AA4

2.11 \$AA5

Description:

Reads the reset status of a module.

Syntax:

\$AA5[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be read (00 to FF)
5	Command to read the module reset status

Response:

Valid Command: **!AAS[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
S	Reset status of the module

1: This is the first time the command has been sent since the module was powered on.

0: This is not the first time the command has been sent since the module was powered on, which denotes that there has been no module reset since the last \$AA5 command was sent.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$015

Response: !011

Reads the reset status of module 01. The response shows that it is the first time the \$AA5 command has been sent since the module was powered-on.

Command: \$015

Response: !010

Reads the reset status of module 01. The response shows that there has been no module reset since the last \$AA5 command was sent.

Related Topics:

Section A.5 Reset Status

2.12 \$AA5VV

Description:

Specifies the channel(s) to count.

Syntax:

\$AA5VV(VV)[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be set (00 to FF)
5	Command to start counting
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the channel is counting and 0 means that the channel is not counting.

Response:

Valid Response: **!AA[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid response
?	Delimiter character for an invalid response. An invalid command is returned if an attempt is made to enable a channel that is not present.
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0153A Response: !01

Sets channels 1, 3, 4, and 5 to count and all other channels not counting for module 01. The module returns a valid response.

Command: \$016 Response: !013A

Reads the counting status of module 01 and returns a response of 3A, meaning that channels 1, 3, 4, and 5 are counting and all other channels are not counting.

Related Commands:

Section 2.13 \$AA6

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.13 \$AA6

Description:

Reads the start/stop counting status of each channel.

Syntax:

\$AA6[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

6 Command to read the channel counting status

Response:

Valid Response: **!AAVV(VV)[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

! Delimiter character for a valid response

? Delimiter character for an invalid response

AA Address of the responding module (00 to FF)

VV A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the channel is counting and 0 means that the channel is not counting.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0153A Response: !01

Sets channels 1, 3, 4, and 5 to count and all other channels not counting for module 01. The module returns a valid response.

Command: \$016 Response: !013A

Reads the counting status of module 01 and returns a response of 3A, meaning that channels 1, 3, 4, and 5 are counting and all other channels are not counting.

Related Commands:

Section 2.12 \$AA5VV

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.14 \$AA6N

Description:

Sets the counter value of a channel to preset value.

Syntax:

\$AA6N[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

6 Command to clear the counter value

N Specifies the channel to be cleared (0 ~ 7)

Response:

Valid command: **!AA[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0161

Response: !01

Clears the counter value of channel 1 of module 01 and the module returns a valid response.

Related Commands:

Section 2.15 \$AA7

Notes:

1. The overflow status is cleared by the command, too.
2. The command is not available to the channels that are set to type code 51, frequency measurement.

2.15 \$AA7

Description:

Reads the counter overflow status of each channel.

Syntax:

\$AA7[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

7 Command to read the counter overflow status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

VV A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. For type code 50, when the bit is 1 it means that the counter of the channel is overflowed and 0 means that the counter of the channel is not overflowed. For type code 54 ~ 56, the overflow status is represented by two bits.

00: no over/underflow
01: overflow
10: underflow
11: not applicable

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$017

Response: !013A

Reads the counter overflow status for module 01 and returns a response of 3A, meaning that counters of channels 1, 3, 4, and 5 are overflowed.

Related Commands:

Section 2.16 \$AA7VV

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.16 \$AA7VV

Description:

Specifies the channels which counter overflow status are to be cleared.

Syntax:

\$AA7VV[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be read (00 to FF)
7	Command to clear the counter overflow status
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the counter overflow status of the channel should be cleared.

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$0173A

Response: !01

Clears the counter overflow status of channels 1, 3, 4, and 5 for module 01 and returns a valid response.

Related Commands:

Section 2.15 \$AA7

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.17 \$AA7CNRVV

Description:

Sets the type code of a channel.

Syntax:

\$AA7CNRVV[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be set (00 to FF)
7	Command to set the channel range code
CN	N specifies the input channel to be set (0-7)
RVV	VV represents the type code of the channel to be set. Refer to the Analog Input Type Setting table in Section 1.9 for details.

Response:

Valid Response: !AA [CHKSUM](CR)

Invalid Response: ?AA[CHKSUM](CR)

! Delimiter character for a valid response

? Delimiter character for an invalid response or
invalid type code

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$017C0R50

Response: !01

Sets the type code for channel 0 of module 01 to be 50 (up counting) and the module returns a valid response.

Command: \$037C1R30

Response: ?03

Sets the type code for channel 1 of module 03 to be 30.

The module returns an invalid response because the type code is invalid.

Related Commands:

Section 2.18 \$AA8CN

Related Topics:

Section 1.9 Configuration Tables

Note:

If the type code of a channel is set to one of 54 ~ 56, then the adjacent channel in the same pair will be set to the same type code.

2.18 \$AA8CN

Description:

Reads the type code information of a channel.

Syntax:

\$AA8CN[CHKSUM](CR)

\$	Delimiter character
AA	Address of the module to be read (00 to FF)
8	Command to read the type code of a channel
CN	N specifies which channel to access for the type code information (N=0-7).

Response:

Valid Response: **!AACNRVV[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid response
?	Delimiter character for an invalid response or invalid channel
AA	Address of the responding module (00 to FF)
CN	N specifies which input channel to access to retrieve the type code information.
RVV	VV represents the type code of the specified input channel. Refer to the Analog Input Type Setting table in Section 1.9 for details.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$018C0

Response: !01C0R50

Reads the channel 0 input range of module 01 and returns 50 (up counting).

Related Commands:

Section 2.17 \$AA7CNRVV

Related Topics:

Section 1.9 Configuration Tables

2.19 \$AAF

Description:

Reads the firmware version of a module.

Syntax:

\$AAF[CHKSUM](CR)

\$	Delimiter character
----	---------------------

AA Address of the module to be read (00 to FF)

F Command to read the firmware version

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
---	---

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

(Data) Firmware version string of the module

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01F Response: !01A2.0

Reads the firmware version of module 01, and shows that it is version A2.0.

Command: \$02F Response: !02B1.1

Reads the firmware version of module 02, and shows that it is version B1.1.

2.20 \$AAI

Description:

Reads the INIT status.

Syntax:

\$AAI[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

I Command to read the INIT status

Response:

Valid Response: **!AAS[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

! Delimiter character for a valid response

? Delimiter character for an invalid response

AA Address of the responding module (00 to FF)

S INIT status:

0= the INIT pin is shorted to GND.

1= the INIT pin is not shorted to GND.

2= Update CJC temperature once only.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01I

Response: !010

Reads the INIT status of module 01 and the module responds with 0, meaning that the INIT pin is shorted to GND.

2.21 \$AAM

Description:

Reads the name of a module.

Syntax:

\$AAM[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

M Command to read the module name

Response:

Valid command: !**AA(Data)**[CHKSUM](CR)

Invalid command: ?**AA**[CHKSUM](CR)

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

(Name) Name string of the module

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01M

Response: !017084

Reads the module name of module 01 and returns the name "7084".

Related Commands:

Section 2.23 ~AAO(Name)

2.22 \$AAP

Description:

Reads the communication protocol information.

Syntax:

\$AAP[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

P Command to read the communication protocol

Response:

Valid Response: !AASC[CHKSUM](CR)

Invalid Response: ?AA[CHKSUM](CR)

! Delimiter character for a valid response

? Delimiter character for an invalid response

AA Address of the responding module (00 to FF)

S The protocols supported by the module

0: only DCON protocol is supported

1: both the DCON and Modbus RTU protocols are supported

C The current protocol that is saved in the EEPROM that will be used at the next power-on reset

0: the protocol set in the EEPROM is DCON

1: the protocol set in the EEPROM is Modbus RTU

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01P

Response: !0110

Reads the communication protocol of module 01 and returns a response of 10 meaning that it supports both the DCON and Modbus RTU protocols and the protocol that will be used at the next power-on reset is DCON.

Related Commands:

Section 2.23 \$AAPN

2.23 \$AAPN

Description:

Sets the communication protocol.

Syntax:

\$AAPN[CHKSUM](CR)

\$ Delimiter character

AA Address of the module to be read (00 to FF)

P Command to set the communication protocol

N 0: DCON protocol

1: Modbus RTU protocols

Before using this command, the rear slide switch must be in the INIT position. The new protocol is saved in the EEPROM and will be effective after the next power-on reset.

Response:

Valid Response: !AASC[CHKSUM](CR)

Invalid Response: ?AA[CHKSUM](CR)

! Delimiter character for a valid response

? Delimiter character for an invalid response

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: \$01P1

Response: ?01

Sets the communication protocol of module 01 to Modbus RTU and returns an invalid response because the module is not in INIT mode.

Command: \$01P1

Response: !01

Sets the communication protocol of module 01 to Modbus RTU and returns a valid response.

Related Commands:

Section 2.22 \$AAP

2.24 @AABB

Description:

Reads the battery backup counter status of each channel.

Syntax:

@AABB[CHKSUM](CR)

@ Delimiter character

AA Address of the module to be read (00 to FF)

BB Command to read the battery backup counter status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

VV A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the battery backup counter is enabled for the channel and 0 means that the battery backup counter is disabled for the channel.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01BB

Response: !013A

Reads the battery backup counter status for module 01 and returns a response of 3A, meaning that battery backup counter for channels 1, 3, 4, and 5 are enabled and disabled for all other channels.

Related Commands:

Section 2.25 @AABBVV

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.25 @AABBVV

Description:

Specifies the channels which battery backup counter function should be enabled.

Syntax:

@AABBVV[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
BB	Command to enable the battery backup counter function
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the battery backup counter is enabled for the channel and 0 means that the battery backup counter is disabled for the channel.

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01BB3A Response: !01

Sets the battery backup counter function of channels 1, 3, 4, and 5 for module 01 to be enabled and returns a valid response.

Related Commands:

Section 2.24 @AABB

Note:

The command is not available to the channels that are set to type code 51, frequency measurement.

2.26 @AAFA

Description:

Reads the automatic frequency mode status of each channel.

Syntax:

@AAFA[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
FA	Command to read the automatic frequency mode status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the automatic frequency mode is enabled for the channel and 0 means that the automatic frequency mode is disabled for the channel.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FA

Response: !013A

Reads the automatic frequency mode status for module 01 and returns a response of 3A, meaning that automatic frequency mode for channels 1, 3, 4, and 5 are enabled and disabled for all other channels.

Related Commands:

Section 2.27 @AAFAVV

Related Topics:

Section A.6 Frequency Measurement

Note:

The command is only available to the channels that are set to type code 51, frequency measurement.

2.27 @AAFAVV

Description:

Specifies the channels which automatic frequency mode is to be enabled.

Syntax:

@AAFAVV[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
FA	Command to enable the automatic frequency mode
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the automatic frequency mode is enabled for the channel and 0 means that the automatic frequency mode is disabled for the channel.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FA3A

Response: !01

Enables the automatic frequency mode of channels 1, 3, 4, and 5 for module 01 and returns a valid response.

Related Commands:

Section 2.26 @AAFA

Related Topics:

Section A.6 Frequency Measurement

Note:

The command is only available to the channels that are set to type code 51, frequency measurement.

2.28 @AAFH

Description:

Reads the high frequency mode status of each channel.

Syntax:

@AAFH[CHKSUM](CR)

@ Delimiter character

AA Address of the module to be read (00 to FF)

FH Command to read the high frequency mode status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

VV A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the high frequency mode is enabled for the channel and 0 means that the high frequency mode is disabled for the channel.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FH

Response: !013A

Reads the high frequency mode status for module 01 and returns a response of 3A, meaning that battery backup counter for channels 1, 3, 4, and 5 are enabled and disabled for all other channels.

Related Commands:

Section 2.29 @AAFHVV

Related Topics:

Section A.6 Frequency Measurement

Note:

The command is only available to the channels that are set to type code 51, frequency measurement.

2.29 @AAFHV

Description:

Specifies the channels which high frequency mode is enabled.

Syntax:

@AAFH[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
FH	Command to enable the high frequency mode
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the high frequency mode is enabled for the channel and 0 means that the high frequency mode is disabled for the channel.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FH3A Response: !01

Enables the high frequency mode of channels 1, 3, 4, and 5 for module 01 and returns a valid response.

Related Commands:

Section 2.28 @AAFH

Related Topics:

Section A.6 Frequency Measurement

Note:

1. The command is only available to the channels that are set to type code 51, frequency measurement.
2. It is recommended to set to high frequency mode for frequency larger than 10 KHz.

2.30 @AAFT

Description:

Reads the frequency measurement timeout setting.

Syntax:

@AAFT[CHKSUM](CR)

@ Delimiter character

AA Address of the module to be read (00 to FF)

FT Command to read the frequency measurement
 timeout setting

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

VV Two hexadecimal digits to represent the timeout
 value in tenths of a second, for example, 01 denotes
 0.1 seconds and FF denotes 25.5 seconds.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FT

Response: !010A

Reads the frequency measurement timeout for module 01 and returns a response of 0A, meaning that frequency measurement timeout value is 1 second.

Related Commands:

Section 2.31 @AAFTVV

Related Topics:

Section A.6 Frequency Measurement

Note:

1. The command is only available to the channels that are set to type code 51, frequency measurement.
2. If there is no input pulse detected during the frequency measurement time out, then the frequency of the channel is set to 0 Hz.

2.31 @AAFTVV

Description:

Sets the frequency measurement time out value of a module.

Syntax:

@AAFTVV[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
FT	Command to set the frequency measurement time out
VV	Two hexadecimal digits to represent the timeout value in tenths of a second, for example, 01 denotes 0.1 seconds and FF denotes 25.5 seconds.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01FT0A

Response: !01

Sets the frequency measurement timeout for module 01 to 1 second and returns a valid response.

Related Commands:

Section 2.30 @AAFT

Related Topics:

Section A.6 Frequency Measurement

Note:

1. The command is only available to the channels that are set to type code 51, frequency measurement.
2. If there is no input pulse detected during the frequency measurement time out, then the frequency of the channel is set to 0 Hz.

2.32 @AAGN

Description:

Reads the preset counter value of channel N.

Syntax:

@AAGN[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be set (00 to FF)
G	Command to read the preset counter value of a channel
N	Specifies the channel to be read (0 ~ 7)

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
(Data)	The preset counter value in eight hexadecimal digits

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01G2 Response: !0100000000

Reads the channel 2 maximum counter value of module 01 and the module responds with 00000000.

Related Commands:

Section 2.33 @AAPN(Data)

Note:

The preset counter value is only available to the channels that are set to up counter type (type code 50).

2.33 @AAPN(Data)

Description:

Sets the preset counter value of a channel.

Syntax:

@AAPN(Data)[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be set (00 to FF)
P	Command to set the preset counter value of a channel
N	Specifies the channel to be read (0 ~ 7)
(Data)	The preset counter value in eight hexadecimal digits

Response:

Valid command: **!AA(Data)[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01P2F0000000 Response: !01

Sets the channel 2 preset counter value of module 01 to 0xF0000000 and returns a valid response.

Related Commands:

Section 2.32 @AAGN

Note:

The preset counter value is only available to the channels that are set to up counter type (type code 50).

2.34 @AASC

Description:

Reads the stop counting on overflow status of each channel.

Syntax:

@AASC[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
SC	Command to read the stop counting on overflow status

Response:

Valid Command: **!AAVV[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the stop counting on overflow is enabled for the channel and 0 means that the stop counting on overflow is disabled for the channel.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01SC

Response: !013A

Reads the stop counting on overflow status for module 01 and returns a response of 3A, meaning that stop counting on overflow for channels 1, 3, 4, and 5 are enabled and disabled for all other channels.

Related Commands:

Section 2.35 @AASCVV

Note:

The command is only available to the channels that are set to type code 50, up counter measurement.

2.35 @AASCVV

Description:

Specifies the channels which stop counting on overflow are enabled.

Syntax:

@AASCVV[CHKSUM](CR)

@	Delimiter character
AA	Address of the module to be read (00 to FF)
SC	Command to enable the stop counting on overflow
VV	A two-digit hexadecimal value, where bit 0 corresponds to channel 0, bit 1 corresponds to channel 1, etc. When the bit is 1 it means that the stop counting on overflow is enabled for the channel and 0 means that the stop counting on overflow is disabled for the channel.

Response:

Valid Command: **!AA[CHKSUM](CR)**

Invalid Command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: @01SC3A

Response: !01

Enables the stop counting on overflow of channels 1, 3, 4, and 5 for module 01 and returns a valid response.

Related Commands:

Section 2.34 @AASC

Note:

The command is only available to the channels that are set to type code 50, up counter measurement.

2.36 ~**

Description:

Notifies all modules that the host is OK.

Syntax:

~[CHKSUM](CR)**

~ Delimiter character

```

**      Host OK command

```

Response:

No response.

Examples:

Command: ~** No response

Sends a “Host OK” command to all modules.

Related Commands:

Section 2.37 ~AA0, Section 2.38 ~AA1, Section 2.39 ~AA2,
Section 2.40 ~AA3E VV

Related Topics:

Section A.2 Dual Watchdog Operation

2.37 ~AA0

Description:

Reads the host watchdog status of a module.

Syntax:

~AA0[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be read (00 to FF)
0	Command to read the module status

Response:

Valid command: **!AASS[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
SS	Two hexadecimal digits that represent the host watchdog status, where: Bit 7: 0 indicates that the host watchdog is disabled, and 1 indicates that the host watchdog is enabled, Bit 2: 1 indicates that a host watchdog timeout has occurred, and 0 indicates that no host watchdog timeout has occurred. The host watchdog status is stored in EEPROM and can only be reset by using the ~AA1 command.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~010

Response: !0100

Reads the host watchdog status of module 01 and returns 00, meaning that the host watchdog is disabled and no host watchdog timeout has occurred.

Command: ~020

Response: !0204

Reads the host watchdog status of module 02 and returns 04, meaning that a host watchdog timeout has occurred.

Related Commands:

Section 2.36 ~**, Section 2.38 ~AA1, Section 2.39 ~AA2, Section 2.40 ~AA3Evv

Related Topics:

Section A.2 Dual Watchdog Operation

2.38 ~AA1

Description:

Resets the host watchdog timeout status of a module.

Syntax:

~AA1[CHKSUM](CR)

~ Delimiter character

AA Address of the module to be reset (00 to FF)

1 Command to reset the host watchdog timeout status

Response:

Valid command: **!AA[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~010

Response: !0104

Reads the host watchdog status of module 01 and shows that a host watchdog timeout has occurred.

Command: ~011

Response: !01

Resets the host watchdog timeout status of module 01 and returns a valid response.

Command: ~010

Response: !0100

Reads the host watchdog status of module 01 and shows that no host watchdog timeout has occurred.

Related Commands:

Section 2.36 ~**, Section 2.37 ~AA0, Section 2.39 ~AA2, Section 2.40 ~AA3EVV

Related Topics:

Section A.2 Dual Watchdog Operation

2.39 ~AA2

Description:

Reads the host watchdog timeout value of a module.

Syntax:

~AA2[CHKSUM](CR)

~ Delimiter character

AA Address of the module to be read (00 to FF)

2 Command to read the host watchdog timeout value

Response:

Valid command : **!AAEVV[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

E 1: the host watchdog is enabled

 0: the host watchdog is disabled

VV Two hexadecimal digits to represent the timeout value in tenths of a second, for example, 01 denotes 0.1 seconds and FF denotes 25.5 seconds.

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~012

Response: !011FF

Reads the host watchdog timeout value of module 01 and returns FF, which denotes that the host watchdog is enabled and the host watchdog timeout value is 25.5 seconds.

Related Commands:

Section 2.36 ~**, Section 2.37 ~AA0, Section 2.38 ~AA1, Section 2.40 ~AA3EVV

Related Topics:

Section A.2 Dual Watchdog Operation

2.40 ~AA3E VV

Description:

Enables/disables the host watchdog and sets the host watchdog timeout value of a module.

Syntax:

~AA3E VV[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be set (00 to FF)
3	Command to set the host watchdog
E	1: enable the host watchdog 0: disable the host watchdog
VV	Two hexadecimal digits to represent the timeout value in tenths of a second, for example, 01 denotes 0.1 seconds and FF denotes 25.5 seconds.

Response:

Valid command: **!AA[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~013164

Response: !01

Enables the host watchdog of module 01 and sets the host watchdog timeout value to 10.0 seconds. The module returns a valid response.

Command: ~012

Response: !01164

Reads the host watchdog timeout value of module 01. The module returns 164, which denotes that the host watchdog is enabled and the host watchdog timeout value is 10.0 seconds.

Related Commands:

Section 2.36 ~**, Section 2.37 ~AA0, Section 2.38 ~AA1, Section 2.39 ~AA2

Related Topics:

Section A.2 Dual Watchdog Operation

Notes:

When a host watchdog timeout occurs, the host watchdog is disabled. The ~AA3EVV command should be sent again to reenable the host watchdog.

2.41 ~AAI

Description:

The Soft INIT command is used to enable modification of the Baud Rate and checksum settings using software only.

Syntax:

~AAI[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be set (00 to FF)
I	Command to set the Soft INIT

Response:

Valid Response: **!AA[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid response
?	Delimiter character for an invalid response
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~01I	Response: !01
Sets the soft INIT of module 01 and returns a valid response.	

Related Commands:

Section 2.1 %AANNTTCFF, Section 2.45 ~AATnn

Related Topics:

Section A.1 INIT Mode

Note:

The ~AATnn command should be sent prior to sending this command, see Section 2.45 for details.

2.42 ~AAO(Name)

Description:

Sets the name of a module.

Syntax:

~AAO(Name)[CHKSUM](CR)

~ Delimiter character

AA Address of the module to be set (00 to FF)

O Command to set the module name

(Name) New name of the module (max. 6 characters).

Response:

Valid command: **!AA[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

! Delimiter character for a valid command

? Delimiter character for an invalid command

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~01O7084N

Response: !01

Sets the name of module 01 to be “7084N” and returns a valid response.

Command: \$01M

Response: !017084N

Reads the name of module 01 and returns the name “7084N”.

Related Commands:

Section 2.21 \$AAM

2.43 ~AARD

Description:

Reads the response delay time value of a module.

Syntax:

~AARD[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be read (00 to FF)
RD	Command to read the response delay time value

Response:

Valid command : **!AAEVV[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)
VV	Two hexadecimal digits to represent the response delay time value in milli-second, for example, 01 denotes 1ms and 1E denotes 30ms. The max allowable value is 30 (1Eh).

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~01RD

Response: !0102

Reads the response delay time value of module 01 and returns 02, which denotes that the response delay time value is 2ms.

Related Commands:

Section 2.44 ~AARDVV

2.44 ~AARDVV

Description:

Sets the response delay time value of a module.

Syntax:

~AARDVV[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be set (00 to FF)
RD	Command to set the response delay time
VV	Two hexadecimal digits to represent the response delay time value in milli-second, for example, 01 denotes 1ms and 1E denotes 30s. The max allowable value is 30 (1Eh).

Response:

Valid command: **!AA[CHKSUM](CR)**

Invalid command: **?AA[CHKSUM](CR)**

!	Delimiter character for a valid command
?	Delimiter character for an invalid command
AA	Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~01RD06

Response: !01

Sets the response delay time value to 6ms. The module returns a valid response.

Command: ~01RD

Response: !0106

Reads the response delay time value of module 01.

The module returns 06, which denotes that the response delay time value is 6ms.

Related Commands:

Section 2.43 ~AARD

2.45 ~AATnn

Description:

Sets the soft INIT time out value.

Syntax:

~AATnn[CHKSUM](CR)

~	Delimiter character
AA	Address of the module to be set (00 to FF)
T	Command to set the soft INIT time out value
nn	Two hexadecimal digits representing the time out value in seconds. The max time out value is 60 seconds. When changing the Baud Rate or checksum settings without altering the INIT* pin, the ~AAI and %AANNTTCCFF commands should be sent consecutively and the time interval between the two commands should be less than the soft INIT time out. If the soft INIT time out is 0, then the Baud Rate and checksum settings cannot be changed using software only. The power on reset value of the soft INIT time out is 0.

Response:

Valid Response: **!AA[CHKSUM](CR)**

Invalid Response: **?AA[CHKSUM](CR)**

! Delimiter character for a valid response

? Delimiter character for an invalid response

AA Address of the responding module (00 to FF)

There will be no response if the command syntax is incorrect, there is a communication error, or there is no module with the specified address.

Examples:

Command: ~01I

Response: !01

Sets the soft INIT of module 01 and returns a valid response.

Command: %0101000700

Response: ?01

Attempts to change the Baud Rate of module 01 to 19200 without first altering the INIT * pin. The module returns an invalid response because the soft INIT time out value is 0.

Command: ~01T10

Response: !01

Sets the soft INIT time out value of module 01 to 16 seconds and returns a valid response.

Command: ~01I

Response: !01

Sets the soft INIT of module 01 and returns a valid response.

Command: %0101000700

Response: !01

Changes the Baud Rate of module 01 to 19200 without first altering INIT * pin. The module returns a valid response.

Related Commands:

Section 2.1 %AANNTTCCFF, Section 2.41 ~AAI

Related Topics:

Section A.1 INIT Mode

Note:

It is recommended that the soft INIT time out value is reset to 0 once any changes to Baud Rate and checksum settings have been completed.

3. Modbus RTU Protocol

The Modbus protocol is developed by Modicon Inc., originally developed for Modicon controllers. Detailed information can be found at <http://www.modicon.com/techpubs/toc7.html>. You can also visit <http://www.modbus.org> to find more valuable information.

The M-7084 modules support the Modbus RTU protocol. The communication Baud Rates range from 1200bps to 115200bps. The parity, data bits and stop bits can be set as N81, N82, E81 and O81. The following Modbus functions are supported.

Function code	Description
01 (0x01)	Read coils
02 (0x02)	Read discrete inputs
03 (0x03)	Read multiple registers
04 (0x04)	Read multiple input registers
05 (0x05)	Write single coil
06 (0x06)	Write single register
15 (0x0F)	Write multiple coils
16 (0x10)	Write multiple registers

If the function specified in the message is not supported, then the module responds as follows.

Error Response

00	Address	1 Byte	1 to 247
01	Function code	1 Byte	Function code + 0x80
02	Exception code	1 Byte	01

If a CRC mismatch occurs, the module will not respond.

3.1 M-7084 Modbus Address Mapping

Address	Description	Attribute
30001 ~ 30016	Counter/frequency value of channel 0 to 7, two registers for each channel	R
40065 ~ 40080	Maximum value for up counter 0 to 7, two registers for each channel	R/W
40097 ~ 40112	Preset value of counter 0 to 7, two registers for each channel	R/W
40161	Frequency measurement timeout in 100ms, 1 ~ 255	R/W
40162	Low-pass filter time for channel 0 and 1 in us, 1 ~ 32767	R/W
40163	Low-pass filter time for channel 2 and 3 in us, 1 ~ 32767	R/W
40164	Low-pass filter time for channel 4 to 7 in us, 1 ~ 32767	R/W
40257 ~ 40264	Type code of channel 0 to 7	R/W
40481	Firmware version (low word)	R
40482	Firmware version (high word)	R
40483	Module name (low word)	R
40484	Module name (high word)	R
40485	Module address, valid range: 1 ~ 247	R/W
40486	Bits 5:0 Baud rate, valid range: 3 ~ 10 Bits 7:6 00: 8 data bits, no parity, 1 stop bit 01: 8 data bits, no parity, 2 stop bit 10: 8 data bits, even parity, 1 stop bit 11: 8 data bits, odd parity, 1 stop bit	R/W
40488	Modbus response delay time in ms, valid range: 0 ~ 30	R/W
40489	Host watchdog timeout value, 0 ~ 255, in 0.1s	R/W
40490	Start/stop counting, bit 0 for ch0, bit 1 for ch1, ..., 00h ~ FFh	R/W
40492	Host watchdog timeout count, write 0 to clear	R/W

Address	Description	Attribute
00033 ~ 00040	Input status after XOR mask for channel 0 to 7	R
00041 ~ 00048	Input status after low-pass filter for channel 0 to 7	R
00065 ~ 00072	Counter overflow status for channel 0 to 7. Write 1 to clear	R/W
00257	Protocol, 0: DCON, 1: Modbus RTU	R/W
00261	1: enable, 0: disable host watchdog	R/W
00269	Data format for frequency type, 0: hex, 1: float	R/W
00270	Host watch dog timeout status, write 1 to clear host watch dog timeout status	R/W
00273	Reset status, 1: first read after powered on, 0: not the first read after powered on	R
00513 ~ 00520	Write 1 to clear counter 0 ~ 7	W
00769 ~ 00776	Enable battery backup for counter 0 to 7	R/W
00801 ~ 00808	Automatic switching between high/low frequency mode for frequency measurement of channel 0 to 7	R/W
00833 ~ 00840	High/low frequency mode for frequency measurement of channel 0 to 7 It is recommended to set to high frequency mode for frequency larger than 10 KHz.	R/W
00865 ~ 00872	Stop counting on counter overflow for channel 0 to 7	R/W
00897 ~ 00904	Enable low pass filter for channel 0 to 7	R/W
00929 ~ 00936	XOR mask for channel 0 to 7	R/W

4. Troubleshooting

If you are having difficulty using the I-7000 or M-7000 module, here are some suggestions that may help. If you cannot find the answers you need in these guides, contact ICP DAS Product Support. Contact information is located in Section 1.12.

4.1 Communicating with the module

If you attempt to communicate with the module and receive no response, first check the following:

- Ensure that the supplied power is within the range of +10 to +30 V DC. If the supplied power is OK, then the power LED should be on.
- When the module receives a command, the power LED is set to “off”. The power LED is shown as “on” after the module responds. This method can be used to check whether the module has received a command sent from the host.
- If possible, use another device to check whether the host can communicate with the device through the same RS-485 network.
- If the host is a PC installed with a Windows operating system, then execute the DCON Utility to determine whether the module can be found. The DCON Utility can be downloaded from the ICP DAS website <http://www.icpdas.com>. The DCON Utility documentation can be found in the **”Getting Started For I-7000 Series Modules”** manual.
- Set the module to “INIT mode” and communicate with the module using the following settings: address 00, Baud Rate 9600bps and no checksum. See Section A.1 for details.

A. Appendix

A.1 INIT Mode

Each I-7000 and M-7000 module has a built-in EEPROM to store configuration information such as module address, type code, Baud Rate, etc. Occasionally, the configuration of a module may be forgotten and there are no visual indications of the configuration of the module. It is difficult to communicate with the module when the configuration of the module is unknown. To help avoid this problem, the I-7000 and M-7000 series has a special mode called “**INIT mode**”. When the module is powered on in “**INIT mode**” the configuration of the module is reset as follows, allowing it to be operated as normal.


1. Address: 00
2. Baud Rate: 9600 bps
3. No checksum
4. Protocol: DCON

The configuration information stored in the EEPROM is not changed and can be read by sending the \$002(CR) command at 9600bps.

There are commands that require the module to be in INIT mode. They are:

1. %AANNTTCCFF when changing the Baud Rate and checksum settings. See Section 2.1 for details.
2. \$AAPN, see Section 2.23 for details.

Originally, the INIT mode is accessed by connecting the INIT* terminal to the GND terminal. New I-7000 and M-7000 modules have the INIT switch located on the rear side of the module to allow easier access to the INIT mode. For these modules, INIT mode is accessed by sliding the INIT switch to the Init position as shown below.



A.2 Dual Watchdog Operation

Dual Watchdog = Module Watchdog + Host Watchdog

The Module Watchdog is a hardware reset circuit that monitors the operating status of the module. While working in harsh or noisy environments, the module may be shut down by external signals. The circuit allows the module to work continuously without disruption.

The Host Watchdog is a software function that monitors the operating status of the host. Its purpose is to prevent problems due to network/communication errors or host malfunctions. When a host watchdog timeout occurs, the module will reset all outputs to a safe state in order to prevent any erroneous operations of the controlled target.

I-7000 and M-7000 series modules include an internal Dual Watchdog, making the control system more reliable and stable.


For more information regarding the Dual Watchdog, please refer to Chapter 5 of the “**Getting Started For I-7000 Series Modules**” manual that can be downloaded from the ICP DAS website <http://www.icpdas.com>.

A.3 Frame Ground


Electronic circuits are constantly vulnerable to Electro-Static Discharge (ESD), which become worse in a continental climate area. Some I-7000 and M-7000 modules feature a new design for the frame ground, which provides a path for bypassing ESD, allowing enhanced static protection (ESD) capability and ensures that the module is more reliable.

Either of the following options will provide a better protection for the module:

1. If the module is DIN rail mounted, connect the DIN rail to the earth ground because the DIN rail is in contact with the upper frame ground as shown in the figure below.
2. Alternatively, connect the lower frame ground terminal to a wire and connect the wire to the earth ground, as shown in the figure below.




New DIN rail models are available that can easily be connected to the earth ground. Each is made of stainless steel, which is stronger than those made of aluminum. There is a screw at one end and a ring terminal is included as shown in the figure below. Refer to Section 1.11.1 for more information about the new DIN rail models.



A.4 Node Information Area

Each I-7000 and M-7000 module has a built-in EEPROM to store configuration information such as module address, type code, Baud Rate, etc. One minor drawback is that there are no visual indications of the configuration of the module. New I-7000 and M-7000 modules include node information areas that are protected by a cover, as shown below, and can be used to make a written record of the node information, such as module address, Baud Rate, etc. To access the node information areas, first slide the covers outward, as shown in the figure below.



A.5 Reset Status

The reset status of a module is set when the module is powered-on or when the module is reset by the module watchdog. It is cleared after the responding of the first \$AA5 command. This can be used to check whether the module had been reset. When the \$AA5 command responds that the reset status is cleared, that means the module has not been reset since the last \$AA5 command was sent. When the \$AA5 command responds that the reset status is set and it is not the first time \$AA5 command is sent, it means the module has been reset and the digital output value had been changed to the power-on value.

A.6 Frequency Measurement

Frequency is usually measured by one of the following two methods.

1. by counting number of signal pulses during a known time interval, gate time
2. by counting number of pulses of a reference clock during the signal period

M-7084 uses the second method for the frequency measurement. It counts number of pulses of the reference clock during one signal period. The drawback of this method is that the resolution will be small when the frequency is high. M-7084 provides the high frequency measurement mode by counting 11 signal periods, instead of only one period, to increase resolution. The high frequency measurement mode can be enabled by @AAFHVV command. Refer to Section 2.29 for details. The side effects of the high frequency measurement mode are that it takes longer time and the counting may overflow when the signal frequency is very low. M-7084 can be set to automatic frequency measurement mode by @AAFAVV command. Refer to Section 2.27 for details. In automatic frequency measurement mode, the channel is switched to the high frequency measurement mode when the signal frequency is high and to the low frequency measurement mode when the signal frequency is low automatically.