

UNOP-1000K

PCIe Expansion Card for UNO-4673A/4683, ECU-4784

Overview

UNOP-1000 equips standard expansion interfaces:


UNOP-1000K: PCIe Expansion card for UNO-4673A, UNO-4683 and ECU-4784

NOTE:

1. The UNO-4673A/4683 only provides PCIe resources on Slot1, that means the PCIe card can only work on Slot 1.
2. The ECU-4784 provides PCIe resources on Slot1 and Slot2, that means the PCIe card can work on Slot1 and Slot2.

Before installing 3rd party plug-in cards, refer to UNO-4673A/4683, ECU-4784 user manual for total thermal/ power consumption information.


Diagram



Installation

Follow the exploded diagrams below for plug-in card installation

- UNOP-1000K



Packing List

Before installation, please make sure that you have received the following:

- 1 x UNOP-1000K unit
- 1 x Front Panel
- 1 x Holder
- 2 x M3 screws
- 1x ROHS LIST
- 1 x UNOP-1000 startup manual
- 1 x warranty card

If anything is missing or damaged, contact your distributor or sales representative immediately.

User Manual

For more detailed information, please refer to the full manual which can be found on the Advantech's website.

Notes

For more information on this and other Advantech

products, please visit our websites at:

<http://www.advantech.com/products/ProView/>

For technical support and service:

<http://www.advantech.com/support/>

This startup manual is for UNOP-1000K

Part No: 2003P10001

2nd Edition

June 2016