


Wire Connection for A I/O


EX9016

Bridge Sensor/Load Cell/Strain
Gauge Wire Connection




EX9016P

Bridge Sensor/Load Cell/Strain
Gauge Wire Connection




EX9016

Analog output wire connection




EX9016P

Analog output wire connection




EX9016

Analog input wire connection



EX9016P


Analog input wire connection



Wire Connection for A I/O


EX9016

Digital Input wire connection




EX9016P

Digital Input wire Connection



EX9016

Digital output wire connection



EX9016P

Digital output wire connection

